



CONTROL



6HB2100-R270

Ref No.	Part Number	Description	Qty	Remarks
1	6CB-48531-00-00	BRACKET, REMOTE CONTROL 1	1	
2	6CB-48532-00-00	BRACKET, REMOTE CONTROL 2	1	
3	97E95-06516-00	BOLT, HEXAGON W/W DEEP RECESS	4	
4	6E5-48538-00-00	CLAMP, CABLE	1	
5	91690-30010-00	PIN, SPRING	1	
6	6E5-48344-00-00	CABLE END, REMOTE CONTROL	1	
7	90468-18008-00	CLIP	1	
8	6CB-44117-00-00	BRACKET	1	
9	95D95-06035-00	BOLT, FLANGE DEEP RECESS	2	
10	69J-44176-01-00	BRACKET	1	
11	93700-06M01-00	NIPPLE, GREASE	1	
12	90386-12069-00	BUSH	2	
13	90109-08019-00	BOLT	1	
14	90508-20052-00	SPRING, TORSION	1	
15	60V-8259F-01-00	SWITCH ASSY	1	
16	69J-8259F-00-00	SWITCH ASSY	1	
17	61A-82588-01-00	PLATE	1	
18	6CB-82588-00-00	PLATE	1	
19	97985-04116-00	SCREW, WITH WASHER	4	
20	6CB-44121-00-00	LEVER, SHIFT ROD	1	

CONTINUED ON NEXT FRAME >



6HB2100-R270


CONTROL

Ref No.	Part Number	Description	Qty	Remarks
21	69J-44122-00-00	BUSHING, SHIFT ROD LEVER	1	
22	90202-08M20-00	WASHER, PLATE	1	
23	90468-18008-00	CLIP	2	
24	90386-06M12-00	BUSH	1	
25	69J-44118-00-00	BRACKET	1	
26	648-42715-00-00	BUSHING 2	1	
27	93501-04M02-00	BALL	1	
28	90501-12082-00	SPRING, COMPRESSION	1	
29	97E75-06535-00	BOLT, HEXAGON W/W DEEP RECESS	1	
30	91690-30010-00	PIN, SPRING	1	
31	6FR-44120-01-00	HANDLE GEAR SHIFT ASSY	1	
32	93210-09165-00	O-RING	1	
33	90386-90M90-00	BUSH	2	
34	90201-09M02-00	WASHER, PLATE	1	
35	91490-20015-00	PIN. COTTER	1	
36	6CB-8A410-11-00	SENSOR UNIT	1	
37	6P2-44139-00-00	..COLLAR	3	
38	6CB-41273-00-00	..GROMMET	3	
39	90119-06297-00	BOLT, WITH WASHER	3	
40	6E5-48344-00-00	CABLE END, REMOTE CONTROL	1	

CONTINUED ON NEXT FRAME >

CONTROL

Ref No.	Part Number	Description	Qty	Remarks
41	90468-18008-00	CLIP	1	



6HB2100-R270