





BRACKET 2

| Ref No. | Part Number     | Description            | Qty | Remarks |
|---------|-----------------|------------------------|-----|---------|
| 1       | 93700-06002-00  | NIPPLE, GREASE         | 1   |         |
| 2       | 90465-08M83-00  | CLAMP                  | 1   |         |
| 3       | 97985-06212-00  | SCREW, WITH WASHER     | 1   |         |
| 4       | 90465-11M10-00  | CLAMP                  | 3   |         |
| 5       | 90465-08M83-00  | CLAMP                  | 1   |         |
| 6       | 97585-06510-00  | BOLT, WITH WASHER      | 1   |         |
| 7       | 90119-10024-00  | BOLT, WITH WASHER      | 8   |         |
| 8       | 6KA-4382A-00-00 | ADAPTOR 1              | 1   |         |
| 9       | 97595-05516-00  | BOLT, WITH WASHER      | 2   |         |
| 10      | 6GR-85887-00-00 | SENSOR, ANGLE          | 1   |         |
| 11      | 93210-17MF9-00  | O-RING                 | 1   |         |
| 12      | 97595-05516-00  | BOLT, WITH WASHER      | 2   |         |
| 13      | 6KF-82553-00-00 | EXTENSION, WIRE LEAD   | 1   |         |
| 14      | 6KA-43126-00-00 | PIN, UPPER SHOCK MOUNT | 1   |         |
| 15      | 91690-60022-00  | PIN, SPRING            | 1   |         |
| 16      | 93210-06ME6-00  | O-RING                 | 1   |         |
| 17      | 90386-18M14-00  | BUSH                   | 2   |         |
| 18      | 6AW-43376-00-00 | BOLT, THRUST RECEIVER  | 2   |         |
| 19      | 95780-10300-00  | NUT, FLANGE            | 2   |         |
| 20      | 6KF-42829-00-00 | PLATE, CLAMP 2         | 1   |         |

CONTINUED ON NEXT FRAME >



# BRACKET 2

| Ref No. | Part Number     | Description       | Qty | Remarks |
|---------|-----------------|-------------------|-----|---------|
| 21      | 97585-06510-00  | BOLT, WITH WASHER | 1   |         |
| 22      | 6KF-42828-00-00 | PLATE, CLAMP      | 1   |         |
| 23      | 90462-08104-00  | CLAMP             | 1   |         |