


POWER TRIM TILT ASSY




6FM1100-R310

Ref No.	Part Number	Description	Qty	Remarks
1	65W-43800-24-CE	POWER TRIM & TILT ASSY	1	
2	65W-43880-21-00	..MOTOR ASSY	1	
3	67C-43805-11-00	...ARMATURE ASSY	1	
4	67C-43804-10-00	...STATOR ASSY	1	
5	67C-43892-10-00	...BRUSH 2	1	
6	67C-82181-10-00	...CIRCUIT BREAKER COMP.	1	
7	67C-4380F-10-00	...PLATE, BRUSH HOLDER	1	
8	67C-4386K-10-00	...SPRING, BRUSH	2	
9	67C-43879-10-00	...SCREW, WITH WASHER	2	
10	97602-04316-00	...SCREW, PAN HEAD WITH WASHER	2	
11	65W-43881-22-00	...FRAME, END	1	
12	67C-43882-10-00	...OIL SEAL	1	
13	67C-43862-10-00	...O-RING	1	
14	65W-43840-01-00	..POWER TILT ASSY	1	
15	65W-4380K-00-00	...CYLINDER, TILT SUB ASSY	1	
16	65W-43810-01-00	...TILT PISTON SUB ASSY	1	
17	65W-43801-01-00	...ROD	1	
18	65W-43812-00-00	...SEAL, DUST	1	
19	65W-43865-00-00	...O-RING	1	
20	65W-43811-01-00	...SCREW, CYLINDER END	1	

CONTINUED ON NEXT FRAME >

POWER TRIM TILT ASSY



Ref No.	Part Number	Description	Qty	Remarks
41	6H1-43866-01-00	...O-RING	1	
42	93210-12N52-00	...O-RING	1	
43	6T4-43853-00-00	..SPRING, MAIN VALVE	1	
44	93210-10M74-00	...O-RING	1	
45	6T4-43808-00-00	..SEAT VALVE COMP. 1	1	
46	62X-43841-00-00	..PISTON, SHUTTLE	1	
47	93210-09165-00	..O-RING	3	
48	65W-43831-00-00	..CONNECTOR, SHAFT	1	
49	65W-43830-00-00	..GEAR PUMP ASSY	1	
50	93505-32038-00	...BALL	2	
51	91318-04025-00	..BOLT	4	
52	65W-43817-00-00	..FILTER 2	2	
53	93210-04N50-00	..O-RING	2	
54	93210-04N51-00	..O-RING	2	
55	6H1-43875-00-00	..RING, SNAP	1	
56	6H1-43845-00-00	..SCREW, MANUAL RELEASE	1	
57	6D8-43863-00-00	..O-RING	1	
58	6H1-43847-00-00	..SEAT, MANUAL VALVE	2	
59	65W-43854-00-00	..SPRING, MANUAL RELEASE	1	
60	65W-4382A-00-00	..ADAPTOR 1	1	

CONTINUED ON NEXT FRAME >

