



FUEL INJECTION PUMP 1



Ref No.	Part Number	Description	Qty	Remarks
1	6CJ-14180-40-00	FLOAT CHAMBER ASSY	1	
2	6C5-14182-20-00	COVER, FLOAT CHAMBER	1	
3	6C5-14985-00-00	FLOAT	1	
4	6C5-14546-10-00	VALVE, NEEDLE	1	
5	6C5-14386-00-00	PIN, FLOAT	1	
6	6C5-2441R-10-00	PLATE, BAFFLE 1	1	
7	6C5-2441T-10-00	PLATE, BAFFLE 2	1	
8	6C5-24453-00-00	SCREW	3	
9	6C5-13906-02-00	REGULATOR, PRESSURE	1	
10	6C5-24592-00-00	BOLT	2	
11	6C5-87226-10-00	WIRE HARNESS ASSY	1	
12	6C5-14960-20-00	BODY ASSY	1	
13	6C5-14191-00-00	PLUG, DRAIN	1	
14	6C5-14397-00-00	O-RING	1	
15	6C5-14567-00-00	SCREW	6	
16	6C5-13910-10-00	FUEL PUMP ASSY	1	
17	6FP-13907-01-00	. FUEL PUMP COMP.	1	
18	6C5-13915-01-00	. .FILTER	1	
19	6C5-14127-10-00	. CLIP	1	
20	6C5-13593-10-00	DAMPER	1	

CONTINUED ON NEXT FRAME >

FUEL INJECTION PUMP 1



Ref No.	Part Number	Description	Qty	Remarks
21	6C5-13781-00-00	DAMPER, PUMP	1	
22	6C5-13716-10-00	COLLAR	1	
23	6C5-14984-10-00	GASKET, FLOAT CHAMBER	1	
24	6C5-21337-10-00	CLAMP, CABLE	1	
25	6C5-14225-00-00	CAP	1	
26	90387-06M03-00	COLLAR	3	
27	69L-85516-01-00	SPACER	3	
28	6C5-13132-00-00	JOINT	1	
29	6C5-13781-10-00	DAMPER, PUMP	1	