



VALVE

Ref No.	Part Number	Description	Qty	Remarks
1	6CJ-12111-00-00	VALVE, INTAKE	8	
2	6CJ-12121-10-00	VALVE, EXHAUST	8	
3	6CJ-12116-00-00	SEAT, VALVE SPRING	16	
4	6CJ-12113-00-00	SPRING, VALVE INNER	16	
5	3LD-12117-00-00	RETAINER, VALVE SPRING	16	
6	3LD-12118-00-00	LOCK, VALVE SPRING RETAINER	32	
7	51Y-12119-00-00	SEAL, VALVE STEM	16	
8	6CJ-12146-00-00	SHAFT, ROCKER	1	
9	6CJ-12151-00-00	ARM, VALVE ROCKER	4	
10	6C5-12159-00-00	SCREW, VALVE ADJUSTING	8	
11	6C5-12158-00-00	NUT, LOCK	8	
12	6CJ-12161-01-00	ARM, VALVE ROCKER 2	8	
13	64J-12159-00-00	SCREW, VALVE ADJUSTING	8	
14	62Y-12158-00-00	NUT, LOCK	8	
15	6CJ-12231-00-00	GUIDE, STOPPER 1	2	
16	6CJ-12233-00-00	PLATE, GUIDE STOPPER 1	2	
17	90201-16014-00	WASHER, PLATE	4	
18	90401-08011-00	BOLT, UNION	5	
19	92990-08200-00	WASHER, PLAIN	3	