


# INTAKE 1

Ref No.	Part Number	Description	Qty	Remarks
1	6FP-13641-00-00	MANIFOLD, INTAKE 1	1	
2	6FP-13645-00-00	..GASKET, MANIFOLD 1	1	
3	6FP-13646-00-00	..GASKET, MANIFOLD 2	1	
4	6FP-13751-01-00	BODY, THROTTLE 1	1	
5	93210-17014-00	..O-RING	1	
6	8GL-85885-01-00	..THROTTLE SENSOR ASSY	1	
7	90149-05041-00	..SCREW	2	
8	6C5-13713-02-00	VALVE, IDLE SPEED CONTROL	1	
9	6FP-13476-00-00	GASKET	1	
10	6FP-13381-00-00	DAMPER	1	
11	68F-83688-10-00	SENSOR ASSY	1	
12	90119-06309-00	BOLT, WITH WASHER	1	
13	90387-06289-00	COLLAR	1	
14	6C5-14496-00-00	.BOLT	3	
15	6C5-81146-10-00	.SCREW 2	2	
16	90464-12183-00	CLAMP	1	
17	90464-17006-00	CLAMP	1	
18	90119-08020-00	BOLT, WITH WASHER	8	
19	6FP-13371-00-00	PLATE	1	
20	6FP-14435-00-00	GROMMET	1	

CONTINUED ON NEXT FRAME >



## INTAKE 1

Ref No.	Part Number	Description	Qty	Remarks
21	91690-50014-00	PIN, SPRING	2	
22	6FP-15373-00-00	PIPE, BREATHER	1	
23	6HV-14440-01-00	SILENCER ASSY, INTAKE	1	
24	90464-65001-00	CLAMP	2	
25	90386-08001-00	BUSH	2	
26	90387-07013-00	COLLAR	1	
27	90119-06307-00	BOLT, WITH WASHER	1	
28	90464-26001-00	CLAMP	2	
29	90464-09M47-00	.CLAMP	1	
30	90464-26001-00	CLAMP	1	