


STARTING MOTOR



Ref No.	Part Number	Description	Qty	Remarks
1	6AW-81800-02-00	STARTING MOTOR ASSY	1	
2	6AW-81830-00-00	..FRONT BRACKET ASSY	1	
3	6AW-81807-02-00	..GEAR ASSY, STARTING MOTOR	1	
4	6AW-81836-00-00	...SHAFT, PINION	1	
5	6AW-81891-01-00	...GEAR, RING	1	
6	6AW-8183T-00-00	...GEAR, IDLER	3	
7	6AW-81832-01-00	...CLUTCH, OVER RUN	1	
8	6AW-81808-00-00	..PINION ASSY	1	
9	6AW-81857-00-00	...PINION STOPPER SET	1	
10	6AW-81862-00-00	..CAP	1	
11	6AW-8183R-01-00	..PLATE	1	
12	6AW-81854-00-00	..BALL, STEEL	1	
13	6AW-81850-00-00	..ARMATURE ASSY	1	
14	6AW-81839-00-00	..LEVER ASSY	1	
15	6AW-81842-00-00	..PACKING	2	
16	6AW-81810-01-00	..STATOR ASSY	1	
17	6AW-81840-00-00	..BRUSH HOLDER ASSY	1	
18	6AW-81820-00-00	..REAR BRACKET ASSY	1	
19	6AW-81826-00-00	..BOLT	1	
20	6AW-81846-00-00	..SCREW	1	

CONTINUED ON NEXT FRAME >

STARTING MOTOR

Ref No.	Part Number	Description	Qty	Remarks
21	6AW-81941-00-00	..STARTER RELAY ASSY	1	

